

ÉCOLE POLYTECHNIQUE FÉDÉRALE
DE LAUSANNE

Optical Engineering: Monomode Fiber

Group	C-8
Students	Loïc AMEZ-DROZ Florian REINHARD
Date of lecture	20.03.2015
Date of final report return	27.03.2015

Abstract

In this study, we analyse the transmission properties of monomode fibers. First we observe transmission light modes using a laser ($\lambda = 633 \text{ nm}$) and the *P1-SMF28E-FC-2* ($\lambda = 1260 \text{ nm}$ to 1625 nm). The different polarizations of a mode are perceptible with a polarizer in different orientations. In the second experience we determinate the numerical aperture of the *P1-630A-FC* fiber ($\text{NA} = 0.11$). Then we measure the transmitted intensity for two numerical apertures. The transmission ratio $r = 1.3$ in favor of the lower NA. Finally we compare the coupling of three different light sources (halogen, LED, laser) into the *P1-630A-FC* fiber.

1 Procedures and results

1.1 Monomode optical fiber injection and mode profiles

We observe the behavior of a laser source through a monomode fiber. Moving the 6 axis positioning system of the fiber entrance and the source, we try to find different modes. The fiber used is the *P1-SMF28E-FC-2* ($\lambda \approx 1.5 \mu\text{m}$).




Fig. 1: Spots resulting from different modes in the fiber.

The wavelength of the laser (633 nm) being smaller than the fiber one we can observe different vibration modes. The image contrasts are caused by the constructive respectively destructive interferences. In the second part we observe the intensity distribution using a polarizer in two different positions (figure 2).





Fig. 2: Rotating the polarizer in front of the source a quarter-turn, we can observe two orthogonal modes. Together they form a mode like in figure 1c.

1.2 Numerical aperture measurement




(a) 0 mm



(b) 237px spot diameter




(c) 2 mm



(d) 410px spot diameter



(e) 5 mm



(f) 690px spot diameter

Fig. 3: Spot diameters with the fiber exit at different distances from the sensor. The size of one pixel is $2.835\ \mu\text{m}$.

Distance from fiber exit to sensor (mm)	Spot diameter (px)	(mm)
0.00	237	0.6719
1.00	340	0.9639
2.00	410	1.1623
3.00	486	1.3778
4.00	551	1.5621
5.00	690	1.9561

Tab. 1: Spot sizes at different positions relative to the fiber exit as measured in figure 3.





Fig. 4: Spot sizes in relation to the distance to the sensor with a line fitted to them. The measurement at 5 mm is considered to be an out-runner, as it is quite noisy (figure 3f). The line's slope of 0.22 is $2 \times \sin \theta$ with θ being half the angle of the maximum angle exiting the fiber.


$$\text{NA} = n \sin \theta = 0.11 \quad (1)$$

The *root mean square* of the difference of the measurements in figure 4 to the fitted line is $\sigma = 0.012$ mm, which yields $\frac{\Delta \text{NA}}{\text{NA}} = 5.4\%$.

1.3 Coupling for different numerical apertures




(a) Low NA.



(b) Line plot for low NA.



(c) High NA.



(d) Line plot for high NA.

Fig. 5: Spots and their line plots with the source at different distances from the fiber entrance and thus different numerical apertures.





Fig. 6: Relative intensities with different numerical apertures at the entrance of the fiber.

The figure 6 suggests that the coupling with the lower numerical aperture is more efficient. This is probably because the lower NA is better adapted to the fiber's acceptance angle.


1.4 Monomode fiber coupling for different sources

To compare the coupling of different sources we use the fiber *P1-630A-FC* ($\lambda = 633 \text{ nm}$) and a planoconvex lens. It is a monomode fiber for these sources.


The laser source is the easiest to be coupled into the *P1-630A-FC* fiber. The laser ($\lambda = 633 \text{ nm}$) has the ideal wavelength and is a coherent source. The coupling is worse with the halogen source, which is an incoherent one. So the closed wavelengths tend to cancel. The fiber's cut-off wavelength is $550 \pm 50 \text{ nm}$. Thus the light is badly transmitted below 500 nm , multimode to 633 nm and monomode after. The coupling with the LED is really dark. Due to its incoherence, the wavelengths close to each other cancel out. The spectrum is narrower than the halogen source's one.



(a) Coupling the halogen source.



(b) Coupling the LED source.



(c) Coupling the laser source.

Fig. 7: Comparison of different light sources being coupled into an optical fiber.

2 Discussion and conclusions

We learned that wavelength and numerical aperture of the source are important for an optimal coupling with optical fibers. It is difficult to couple incoherent light into a fiber. When there are several modes in a fiber, then they are very unstable and prone to perturbations, such as movements of the fiber, changes in polarization of the source, and position as well as orientation of the source in relation the the fiber's entrance.